

Product Evaluation

DR773 | 0916

Engineering Services Program

The following product has been evaluated for compliance with the wind loads specified in the International Residential Code (IRC) and the International Building Code (IBC).

This product evaluation is not an endorsement of this product or a recommendation that this product be used. The Texas Department of Insurance has not authorized the use of any information contained in the product evaluation for advertising, or other commercial or promotional purpose.

This product evaluation is intended for use by those individuals who are following the design wind load criteria in Chapter 3 of the IRC and Section 1609 of the IBC. The design loads determined for the building or structure shall not exceed the design load rating specified for the products shown in the limitations section of this product evaluation. This product evaluation does not relieve a Texas licensed engineer of his responsibilities as outlined in the Texas Insurance Code, the Texas Administrative Code, and the Texas Engineering Practice Act.

For more information, contact TDI Engineering Services Program at (800) 248-6032.

Evaluation ID: DR-773 **Effective Date:** September 1, 2016

Re-evaluation Date: July 2020

Product Name: Heritage Wood Gardenaire Sidelite, Non-impact Resistant

Manufacturer: Kolbe & Kolbe Millwork Co., Inc.

1323 South Eleventh Avenue

Wausau, WI 54401 (715) 842-5666

General Description:

System	Description	Label Rating	Design Pressure Rating	Hallmark Certification
1	Heritage Wood Gardenaire Sidelite; Narrow Stiles	CW-PG70 50.50 x 98.44-FD CW-PG70 51 x 98-FD	+70- / -75 psf	413-H-1277.00 413-H-1277.01

Product Dimensions:

System	Overall Size	Panel Size	Panel Glass Daylight Opening Size
1	50-1/2" x 98-7/16"	48-1/4" x 95-11/16"	43-1/4" x 91"

Product Identification (Certification Label on Window):

System			
	Certification Agency	WDMA	
	Manufacturer's Name or Code Name	Kolbe & Kolbe Millwork Co., Inc.	
1	Product Name	Heritage Gardenaire Single Wide Fixed	
	Tost Standards	AAMA/WDMA/CSA 101/I.S.2/A440-11	
	Test Standards	AAMA/WDMA/CSA 101/I.S.2/A440-08	

Impact Resistance:

System	Impact Resistant	Requirement	
1	No	Provide an impact protective system when installing the product in	
		areas that require windborne debris protection.	

Installation:

Option 1: The assembly must be fastened to minimum Southern Yellow Pine lumber. The assembly is secured to the wall framing using Kolbe & Kolbe metal installation clips. The installation clips $(1-5/8" \times 10-1/16" \times 0.04")$ are secured to the window frame side jambs, head, and sill. The clips are secured to the frame with two No. 8 x 3/4" screws. The clips are secured to the wall framing with one No. 8 x 1-3/4" screw. The fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing. The spacing of the clips is specified in the table below.

Installation Clip Spacing:

System	Distance From Each Corner	Head (on center spacing)	Sill (on center spacing)	Side Jambs (on center spacing)
1	Head: 16-7/8" Side Jambs: 12-5/16"	16-7/8"	See below	12-5/16"

Sill: Secure the sill with minimum No. 10 x 2-1/4" PFH screws located approximately 4" from each corner and 10" on center.

Option 2: The assembly must be fastened to minimum Southern Yellow Pine lumber. The assembly is secured to the wall framing using the window frame with minimum No. 10 x 2-1/2" screws. The fasteners must be long enough to penetrate a minimum of 1-1/2" into the wall framing. The spacing of the fasteners is specified in the table below.

Fastener Spacing:

System	Distance From Each Corner	Head (on center spacing)	Sill (on center spacing)	Side Jambs (on center spacing)
1	Head: 12-5/8" Side Jambs: 8-15/16"	12-5/8"	See below	8-15/16"

Sill: Secure the sill with minimum No. 10 x 2-1/4" PFH screws located approximately 4" from each corner and 10" on center.

Brickmould: The brickmould of the assembly is secured to the wall framing with 2-1/2" T-nails. The fasteners are spaced approximately 12" on center along the head and 24" on center along the side jambs.

Note: Keep the manufacturer's installation instructions available on the job site during installation. Use corrosion resistant fasteners as specified in the IRC, the IBC, and the Texas Revisions.